


Assembly Instructions

Axle and wheel assembly on the ACC 4 Transport Case



Retro fit wheels-kit consisting of:

- · Axle for transport box (1x)
- · Wheel for transport box (2x)
- · Split pin (2x)
- · Flat gasket EPDM 65 size 8x18x2 mm (2x)
- · Hexagon head screw with flange DIN 6921 M8 x 25 (2x)
- · Washer DIN 125 21x37x3 A2 (4x)
- · Hexagon nut with clamping part DIN 985 M8 A2 (2x)





Preparation of the ACC 4 Case:

1. Take out the foam.







2. Drill holes at predrilled recesses from the inside to the outside (use an 8 mm drill bit).











Mounting the axis:

- 1. Place the flat gasket in the recesses provided in the axis.
- 2. Insert the screws from below through the welded connecting piece of the axis.
- 3. Place the axis together with the screws in position and guide the screws through the wall of the ACC Transport Case.







- 4. Secure the screws from the inside with hexagon nuts. Use a 13 mm wrench.
- 5. View of the outside.








Mounting the wheels:

- 1. Slide one washer on each side of the axle.
- 2. Position one wheel per side on the axle.
- 3. Slide one washer on each side of the axle again.
- 4. Thread the end of the split pin through the hole provided and fold it over.









fold it over