

ZORN Digital on the construction

Simple, fast evaluation of the
measurement results on site

ZFG ViewerApp

► Free mobile app for LWD data

Using the ZFG Viewer App you can transfer measurement data from ZORN LWD models ZFG 3000, ZFG 3.1, and ZFG 3.0 and display results on your personal smartphone or tablet computer. Data is transferred via Wi-Fi. You can check and compare values for individual test positions (E_{vd} modulus, deflection, s/v) and the respective measurement curves.

You can forward LWD test data in the original ZFG format or as ZIP file by email. Data can then be further processed e.g., with the ZORN FG-WebApp.

The ZFG Viewer App also allows to create test protocols in a basic PDF format. Forwarding original data or test reports requires a working email client on your smartphone or tablet computer.

GPS data of each test position, if available, can be viewed via Google Maps.

ZORN FG-WebApp

► Full browser-based LWD report software

This new web-browser based application helps you create measurement reports for ZORN Light Weight Deflectometers, starting with models ZFG 3.0 and 3000.

ZORN FG-WebApp can be used on both classic desktop computers and mobile devices. Import measurement data from your ZFG LWD easily via Wi-Fi or SD card. Then evaluate results and edit high-quality test reports independent of time and place, directly on site or later, at the office. Forward original data or final PDF reports via email or messenger.

- Runs in most web browsers without installation
- Works on most MS Windows, iOS desktop and mobile devices
- Safe, independent, always up-to-date
- Offline use possible
- Independent of time and place
- One-off user registration required with immediate free trial access
- Longtime users need to apply for a license
- Ask your local ZORN dealer

ZORN D plus App

► Wireless control app for ZORN LWDs

Go fully wireless with your new ZORN LWD. Or, turn your tried and tested ZFG into the most modern.

ZORN LWD add-on D plus connects any ZORN LWD device to your mobile phone or tablet via Bluetooth.

Simply plug the ultra-light ZORN D plus into the LWD sensor Socket. Then start your free ZORN D plus App and connect the D plus to your smartphone or tablet via Bluetooth.

The app allows full control of the LWD device during measurements and the subsequent creation of full, high quality test reports.

- Incl. ground temperature info
- Measured by the ZORN D plus as well as GPS coordinates collected directly at the test position.
- Make full use of data obtained during LWD measurements (E_{vd} modulus, single and mean deflection values, s/v relation, deflection curves)
- Add photos and text information on soil material, weather conditions, site characteristics and more.

This App comes free with every purchase of a ZORN D plus wireless kit.